



NOTES:

1. PRIOR TO PAVING, CONTRACTOR MUST SCHEDULE WITH CITY TO TEST WIRE FOR ELECTRICAL CONTINUITY.
2. INSTALL ELECTRICAL WATER TIGHT CONNECTORS (GEL PACKS) THAT SNAP TOGETHER AT ALL SPLICES.
3. WIRE REQUIRED ON ALL WATER MAINS AND PRESSURE SEWER MAINS.



TRACER WIRE INSTALLATION

PUBLIC WORKS ENGINEERING

APPR. BY: SAW

DATE: 01.24

DRAWN BY: JLR

DWG: W12

CAD FILE: 2012_W12_01_2024