



**ELEVATION**

**NOTE:**

1. INSTALL 8"–10" TAIL PIECE OF TRACER WIRE INSIDE EVERY VALVE BOX. IF THE DISTANCE BETWEEN VALVE BOXES OR RISERS IS GREATER THAN 300'. INSTALL CARSONITE WATER SERVICE MARKER WITH TRACER WIRE.



**2" IRRIGATION  
DISTRIBUTION  
BLOW-OFF**

PUBLIC WORKS ENGINEERING	
APPR. BY: PKR	DATE: 12.2010
DRAWN BY: SC NYBY	DWG: IRR2
CAD FILE: 2012_IRR2_12_2010	